






ECU plug (wired end)

1	Ignition control signal output	18	Ignition control signal output
2	Ignition control signal output	19	Ignition control signal output
3	Ignition control signal output	20	Ignition control signal output
4	Ignition control signal output	21	Ignition control signal output
5	Ignition control signal output	22	Ignition control signal output
6	Ignition control signal output	23	Ignition control signal output
7	Ignition control signal output	24	Ignition control signal output
8	Ignition control signal output	25	Ignition control signal output
9	Ignition control signal output	26	Ignition control signal output
10	Ignition control signal output	27	Ignition control signal output
11	Ignition control signal output	28	Ignition control signal output
12	Ignition control signal output	29	Ignition control signal output
13	Ignition control signal output	30	Ignition control signal output
14	Ignition control signal output	31	Ignition control signal output
15	Ignition control signal output	32	Ignition control signal output
16	Ignition control signal output	33	Ignition control signal output
17	Ignition control signal output	34	Ignition control signal output



名称	电气原理图	型号	TC300
代号			
设计	张业军	20230610	
校核			
审核			
定稿			
共 1 页	第 1 页	第 1 版	